

ZENVIDA

Product name: Zenvida Over Toilet
Storage Cabinet
SKU:285-OVRTLTCBNT
Email: priority@zenvidahome.com
Tel: 855-349-4327
[http:// bit.ly/ZENVI](http://bit.ly/ZENVI)





Reaching out via product review, marketplace email, social media or leaving seller feedback may cause a delay in response. If you have questions about this product or need anything, please contact us . You are our priority!

WARNING

Power tools may strip bolts or screws. Hand tighten bolts to only about 75% tight. Do Not completely tighten any bolt during assembly until all bolts are connected.

EMAIL: priority@zenvidahome.com WEB: <http://bit.ly/ZENVIDA> TEL: 855-349-4327



hardware

(H1) x 30
wooden dowel
Ø6x30L




(H2) x 22
cam lock bolt




(H3) x 22
cam lock




(H4) x 22
cam lock cap




(H5) x 2
handle




(H6) x 4
screw for handle
Ø4x16L



(H7) x 1
magnet




(H8) x 2
screw for magnet
Ø3x16L




(H9) x 8
screw
Ø3x12L




(H10) x 4
bolt Ø6x45L




(H11) x 4
barrel nut




(H12) x 4
shelf support



(H13) x 20
screw Ø2.2x10L




(H14) x 1
screw Ø4x16L




(H15) x 1
strap






(H16) x 3
plastic anchor



(H17) x 3
screw Ø4x40L



step 1.






(H1) x 2
wooden dowel
Ø6x30L

(H2) x 2
cam lock bolt




(H3) x 2
cam lock

(H4) x 2
cam lock cap



1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.

step 2.




(H1) x 2

wooden dowel
Ø6x30L



(H2) x 2

cam lock bolt




(H3) x 2

cam lock




(H4) x 2

cam lock cap






1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.

step 3.




Must place Part E by the tag indicated direction strictly to ensure all the other position fit well.

step 4.



(H1) x 4
wooden dowel
Ø6x30L




(H2) x 4
cam lock bolt




(H3) x 4
cam lock




(H7) x 1
magnet



(H8) x 2
screw for magnet
Ø3x16L




(H4) x 4
cam lock cap




1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.


step 5.





(H5) x 2
handle



(H6) x 4
screw for handle
Ø4x16L





(H9) x 8
screw
Ø3x12L







step 6.

(H13) x 20 (H14) x 1 (H15) x 1
screw Ø2.2x10L screw Ø4x16L strap



Attach back panel (1) using hardware (H13).
Attach strap (H15) to back of Etagere's top panel profile (see drawing
for reference) with screw (H14)





step 7.




LOW

HIGHT



Adjust part N rail height behind toilet
to ensure toilet go in.

(H1) x 5 wooden dowel Ø6x30L	(H2) x 3 cam lock bolt	(H3) x 3 cam lock	(H4) x 3 cam lock cap
			



1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.

step 8.







(H1) x 5
wooden dowel
Ø6x30L

(H2) x 3
cam lock bolt




(H3) x 3
cam lock

(H4) x 3
cam lock cap




1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.

step 9.



(H1) x 8
wooden dowel
Ø6x30L




(H2) x 8
cam lock bolt



(H3) x 8
cam lock





(H4) x 8
cam lock cap



1. Screw-in cam lock bolts must be screwed down flush.
2. Carefully tap wooden dowels into place.
3. Refer to page 6 for instructions on how to use the cam lock system.

step 10.

(H12) x 4
shelf support




step 11.

When positioned against the wall, mark the holes where hardware H16/H17 should be inserted.

Then move the etagere away from the wall to drill $\varnothing 17/64$ " holes.




Tap in wall anchor.

Position the etagere back against the wall and fasten etagere to the wall with hardware H17.



(H16) x 2
plastic anchor

(H17) x 2
screw $\varnothing 4 \times 40L$



With Etagere positioned against wall, mark where strap end should attach to wall. Move armoire back away from wall in order to drill $17/64$ " hole in wall. Tap in wall anchor.


step 12.

Position against wall


Mark position of bracket hole on wall

Drill 17/64" hole



Tap in wall anchor



(H16) x 1
plastic anchor



(H17) x 1
screw Ø4x40L



Secure strap (H15) to wall by screwing hardware screw (H17) into plastic wall anchor (H16).